










Assembly Instructions

For Tent Size : 240x240x200-230cm
300x300x200-230cm


COMPONENTS

(A) Tent, (B) Floor Tray,
(D-F) Corner Adapter, (1-5) Framework Support




- | | | |
|----------|---|--------|
| 1 |  | 9 pcs |
| 2 |  | 9 pcs |
| 3 |  | 20 pcs |
| |  | 4 pcs |
| |  | 4 pcs |

STEP 1




Assemble frame as above show .

STEP 2



Unzip all zippers of the tent cover all the way.
Gently pull up the top of tent shell on the frame
make sure all corners are squarely in place.
Having a helper makes this process easier.

STEP 3



Pull the bottom of tent shell to cover
the base of tent frame properly.
Put all hanging bars on the top of frame.

